

How to Get the Best Picture

Only applicable with a High Definition TV

Know your TV:



Most HDTVs
Wide Screen



Standard Definition (SD)
and some HDTVs
Regular Screen

Make the right connection:

The HDTV input used on my TV to view satellite TV programming is _____.


HDTV Input

My receiver is connected to the HDTV with this type of connector (check box):

HDTV Digital Audio/Video



Component



Know what screen resolution works best with your HDTV:

Your receiver can be set up for one of three resolution settings to make the best picture for use with your HDTV. Settings are:



1080i - The HDTV resolution recommended for most HDTVs.

720p - Also an HDTV resolution, but not supported on some HDTVs.

480p - Not an HDTV resolution, but ideal for enhanced definition TVs (EDTVs).

To check your resolution settings, on your remote press MENU, select 6, then 7 to go to the HDTV Setup screen.

I use _____ TV Type resolution to view HDTV.

1080i or 720p
(480p only for EDTVs)

Watch an HDTV channel:

High definition channels can be found in the
9420 to **9499** channel range.

Understand the screen formatting options:

Press the FORMAT button on your remote to change your picture shape to your preference. See your HDTV user's guide for formatting options available on your HDTV.



What you may see on your HDTV:

Bars on your screen

The difference between the shape of your screen and the shape of the programming may result in bars displayed at the top/bottom or sides.



Standard definition programs

While standard definition offers great picture quality, nothing compares to HD programming.

